

SkyROLL

ELECTRIC / RADIO / SOLAR ROLLER SHUTTER



General comments

Please read the instructions carefully before attempting assembly. To ensure proper functioning and safe operation of the product, follow the directions in this manual. Please keep it for possible future use and pass it on to any new user.

Content

- a. M6x15 screw (4 pcs)
- b. M6 nut (4 pcs)
- c. Self-drilling screw
- d. M4x20 screw (2 pcs)
- e. M4 nut (2 pcs)
- f. O-ring (2)
- g. Bottom slide (2 pcs.)
- h. Stencil (1)




Fig.1

Tools

- Drill
- Drill bit $\varnothing 6$
- Drill bit $\varnothing 4$
- Allen key 4
- Allen key 3
- Phillips screwdriver

Assembly

- 1) Before installation, unpack the roller shutter and check if there are all the elements necessary to install it (in accordance with the "Contents" section) and prepare the required tools (in the "Tools" section). Do not install an incomplete roller shutter!
- 2) Customize a template [h] to the edge of the upper (transverse) sheet of the window cladding (Fig.2). Then drill 2 holes with a $\varnothing 6$ drill bit. Turn the template over and repeat in the opposite corner (Fig.3)





Fig.2




Fig. 3

- 3) Apply the slide **[g]** to the lower edge of the sash (Fig. 5 & 6)





Fig. 5

Fig. 6

- 4) Use a $\varnothing 4$ drill bit to drill a hole in the bottom sheathing of the sheet metal (Fig. 7) and then fasten the **M4x20** screw **[d]**, M4 nut **[e]** and O-ring **[f]** with the kit as shown in (Fig. 8)





Fig. 7

Fig. 8

- 5) Screw the lower part of the slide **[g]** with a self-drilling screw (Fig. 9). Repeat the steps for the second slide (Fig. 10)





Fig. 9

Fig. 10

6) Insert the lower part of the roller shutter guides into the previously attached slides (Fig.11 and 12)



Fig.11




Fig.12

7) Fasten the top hinges with M6x15 screws [a]



Fig.13




Fig.14





Fig.15 Fig.16

8) Bring in the electrical cord. The cable should be inserted without damaging the window and the sealing flashing around the window.